

Better Packages BP-6 Label Moistener

Instructions



Figure #1



Figure #2

1. Remove **BP-6 Label Moistener** from carton. It will contain one unit with a moistening brush.
2. Be sure brush is angled in the direction as shown in figure #1.
3. Open lid and fill reservoir with 1 ½ inches of water. **DO NOT OVERFILL.**
4. Close lid and you are ready to use your BP-6 Label Moistener.
5. To moisten label, slide the label (adhesive down) under the metal guide as seen in figure #2.
6. As you slide the label under the metal guide, pull it in a downward direction for best results.

Thank you for purchasing this Better Packages product. It was proudly made in U.S.A.